



Companion Cart

MOTORIZED DEAD STOCK REMOVAL CART

Purpose-built motorized solution designed specifically for **the removal of pig carcasses in swine production facilities**. Engineered to withstand the demanding conditions of commercial farm environments, it delivers consistent and reliable performance in one of the most physically challenging tasks on the farm floor.

With integrated motor assistance, the Companion Cart significantly reduces the physical strain associated with carcass removal, improving operator safety, minimizing handling time, and streamlining overall workflow efficiency.



Key advantages

▶ Effortless

Allows you to move loads weighing up to 350 lbs (160 kg) with absolutely no effort.

▶ Affordable motorized solution

Provides a cost-effective, motorized option that reduces physical strain and boosts productivity.

▶ Minimal maintenance

Forget the complications. Companion Cart requires no lubrication and is easy to clean and maintain. Its puncture-resistant tires ensure consistent and reliable performance, day after day.



Puncture-proof tires

Designed for repeated use, these puncture-proof, urethane-filled all-terrain tires ensure reliable performance across various terrains, providing enhanced durability and minimizing downtime.



Intuitive control panel

The easy-to-use control panel offers simple operation with forward, reverse, and neutral settings, allowing for smooth and controlled movement.



Powerful winch

With a 2000 lbs capacity and a 24 V electric system, this winch is built to handle heavy loads with efficiency and durability.

Technical specifications

Size (H,W,L)	42" x 23 1/4" x 61" (107 cm x 59 cm x 155 cm)
Weight	165 lbs (75 kg)
Corner Maneuverability	36" x 36" (91 cm x 91 cm)
Material	Aluminum
Forward and reverse speed	190 ft/min (3.5 km/h) and 160 ft/min (3.0 km/h)
Motor	24 V, 300 W
Max lifting capacity	350 lbs/160 kg
Speed control	Mechanical Variable Belt System
Flat-proof all-terrain tires	Included
Autonomy	3 hours (normal use)



1-877-776-6246

www.imv-technologies.com

